Polaroid



WIRELESS SPORT EARBUDS

{ WITH IN-LINE MIC }

PBT91 | USER MANUAL

Questions? Need some help? The manual will help you enjoy your new product

If you still have questions, call us toll free: **1-877-768-8481**

or visit us at: **www.southerntelecom.com** Click on "Product Support"

IN THE BOX



Wireless Sport Earbuds

User Manual

Micro USB Charging Cable

LOCATION OF CONTROLS



1. **[+] button:**
   - Long press = increase volume
   - Quick press = skip to previous song
   - Double press = disconnect Bluetooth
2. **[❨] button:**
   - Long press = power ON/OFF
   - Quick press = play/pause; answer/end call
3. **[-] button:**
   - Long press = decrease volume
   - Quick press = skip to next song
4. LED indicator light
5. Micro USB charging port

CHARGING THE EARBUDS

1. Plug the small end of the Micro USB charging cable into the Micro USB charging port on the earbuds.
2. Plug the large end of the Micro USB charging cable into a USB port on your computer or other USB charging device.
3. The LED charging indicator light is RED when charging. It will shut off when the earbuds are fully charged.



Make sure you charge the earbuds for at least 3 to 4 hours before using it for the first time.

PAIRING THE EARBUDS

1. Long press the **[❨]** button until a tone is heard and the LED Bluetooth indicator light quickly flashes BLUE.
2. Keep the earbuds and Bluetooth enabled device within 3 feet of each other during the pairing process.
3. Set your Bluetooth enabled device to search for Bluetooth devices.

If there are no paired devices in range when the earbuds are turned on, it will go into pairing mode automatically. If a paired device is in range, the earbuds will connect to it automatically.

On an iPhone
- Go to SETTINGS > BLUETOOTH (Make sure Bluetooth is turned ON)

PAIRING THE EARBUDS (cont'd)

On a Blackberry
- Go to SETTINGS/OPTIONS > BLUETOOTH
- Enable BLUETOOTH

On an Android Phone
- Go to SETTINGS > BLUETOOTH > MENU > Search for devices (Make sure Bluetooth is turned ON)

PAIRING THE EARBUDS (cont'd)

On other Cell Phones/Devices
- Review the instruction manual that came with your phone/device.



4. When the Bluetooth enabled device finds the earbuds, select "PBT91" from the list of found devices.
5. If required, enter the password 0000. Select OK or Yes to pair the two units.
6. After a successful registration, a tone will be heard and the LED Bluetooth indicator light will flash BLUE slowly.

NOTE: If you would like to connect the earbuds to another device, you must unpair them from the currently paired device first. In your device's Bluetooth settings, select "PBT91," then select "unpair." When the earbuds have been unpaired, they automatically go into pairing mode again.

The screenshots above are typical of many Bluetooth enabled devices in the market today, and are used to assist in the explanation of the pairing process. Your Bluetooth enabled device's interface and interaction with the Bluetooth earbuds may slightly differ from the illustrations above.

USING THE EARBUDS

Powering ON/OFF
- Long press the **[❨]** button to turn ON and OFF.
- Check that your Bluetooth features are turned ON. If you have already paired the earbuds with a Bluetooth enabled device, it will automatically connect.
- If you are using the earbuds for the first time, go to the "PAIRING THE EARBUDS" section of this User Manual, and pair the earbuds to your desired Bluetooth device.

Adjusting the volume
- Long press the **[+]** button to increase the volume.
- Long press the **[-]** button to decrease the volume.

Answering/ending a call
- To answer a call, quick press the **[❨]** button.
- To end a call, quick press the **[❨]** button.

PLAYING MUSIC

To enjoy wireless music on your Bluetooth earbuds, make sure you are connected to a Bluetooth enabled device (see "PAIRING THE EARBUDS"). Once connected, press PLAY on your Bluetooth device. When playback has begun, control the music and volume with your connected device or the buttons on the earbuds.

Play/Pause
- Quick press the **[❨]** button to pause the music.
- To resume music playback, quick press the **[❨]** button again.

Skipping Songs
- Quick press the **[+]** button to skip to the previous song.
- Quick press the **[-]** button to skip to the next song.

Adjusting the volume
- Long press the **[+]** button to increase the volume.
- Long press the **[-]** button to decrease the volume.

TROUBLESHOOTING

I can pair the Bluetooth earbuds with my Bluetooth device, but I cannot hear any music.

1. Make sure your Bluetooth device supports A2DP profile.
2. Turn up the volume on your Bluetooth device.
3. You may have to unpair the earbuds, then re-pair to your device.

My Bluetooth device is not able to pair with the Bluetooth earbuds.

1. Long press the **[❨]** button until a tone is heard and the LED Bluetooth indicator light quickly flashes BLUE.
2. Keep your Bluetooth earbuds and Bluetooth enabled device within 3 feet of each other during the pairing process.
3. Check that YOUR device's Bluetooth feature is turned ON.
4. Try repeating the pairing process. See "PAIRING THE EARBUDS."
5. Make sure the earbuds are fully charged.

TROUBLESHOOTING (cont'd)

I cannot get the Bluetooth earbuds into pairing mode.

1. Make sure the Bluetooth earbuds are turned ON before beginning the pairing process.
2. Long press the **[❨]** button until a tone is heard and the LED Bluetooth indicator light quickly flashes BLUE.
3. The earbuds are now in pairing mode.

LEGAL

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

AIT, Inc.
AIT/TK Customer Service (2nd Floor)
14-C 53rd Street
Brooklyn, NY 11232

IN NO EVENT WILL AIT, ITS MANUFACTURERS, DISTRIBUTORS OR PLR IP HOLDINGS, LLC BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) RELATED TO THIS PRODUCT EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY.

Questions? Need some help? The manual will help you enjoy your new product

If you still have questions, call us toll free: **1-877-768-8481**

or visit us at: **www.southerntelecom.com** Click on "Product Support"

Polaroid

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Hereby, Polaroid declares that this [wireless device] is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

All of these warranties are designed to provide appropriate protection against normal interference in a residential environment and normal operation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

PLR IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment, and to avoid incurring accelerated fees, we have properly disposed of this product in compliance with all applicable regulations. Products or other components at their expiration of life should not be disposed of in unsorted municipal waste. Please recycle your product locally. Please visit our electronic waste initiatives or the nearest online Purchased Polaroid products to determine a location where you can appropriately dispose of the product.

Polaroid and its licensees disclaim liability for any damages caused by the use of this product in connection with any other equipment, including but not limited to personal computers, cellular phones, and other consumer electronics. Polaroid and its licensees disclaim liability for any damages caused by the failure of this product to operate properly when used with any other equipment, including but not limited to personal computers, cellular phones, and other consumer electronics. Polaroid and its licensees disclaim liability for any damages caused by the failure of this product to operate properly when used with any other equipment, including but not limited to personal computers, cellular phones, and other consumer electronics.

Polaroid and its licensees disclaim liability for any damages caused by the failure of this product to operate properly when used with any other equipment, including but not limited to personal computers, cellular phones, and other consumer electronics.